

Biolytix MultiPod Wiring Instructions

1. To connect main power to control box on Tank #1 (BioPod)



- Connect a RCBO protected power supply to the controller's Earth, Phase and Neutral supply (terminals 1 to 3 respectively), through the conduit provided into the junction box on the outside of the control box.

2. To connect Tank #1 (BioPod) and Tank #2 (EcoPod)

Tank # 1 (BioPod)



Tank # 2 (EcoPod)



- There is a conduit gland and 5-core cable on the side of **Tank #1 (BioPod)** just below the join between the lid directly under the main control box.
- Take that cable across to **Tank # 2 (EcoPod)** and connect to the junction box attached to the outside of the lid.
- Connect the 5-core cable as follows:



- L = Brown
- N = Blue
- Earth = Green
- 1 = White
- 2 = Orange

- Once power on check pump in EcoPod operates when float raised. Check alarm functions when high level (top) float raised.